

FRONT DOOR JAMB · NOISE CONTROL

SBR RUBBER DOOR JAMB STRIP

Fabric-reinforced, adhesive-backed SBR rubber strip that quiets the Portland Loo's front door when it closes.

**36" x 1" x 1/4"**

4 STRIPS PER FRONT DOOR

75A durometer

HARD, HIGHLY SHAPE RETAINING

Fabric reinforced

POLYESTER PLY EVERY 1/16"

Peel & stick

ACRYLIC ADHESIVE BACKING

OVERVIEW

This black SBR (styrene butadiene rubber) strip lines the Portland Loo's front door jamb. Together with a properly adjusted door closer, it cushions the door as it closes, cutting down on slamming and on the natural echo of the Loo's stainless steel structure.

A layer of polyester fabric every 1/16" through the thickness keeps the strip from flattening or stretching under repeated heavy compression, so it keeps doing its job. It is a different material from the foam used on the chase door, so be sure to ask for the SBR rubber strip when ordering.

KEY FEATURES

01 Quieter closing

Absorbs door impact and reduces slamming noise and echo in the stainless structure.

03 Ultra abrasion resistant

Industrial-grade rubber that stands up to constant door contact.

02 Holds its shape

Fabric reinforcement resists compression set and tearing better than plain SBR.

04 Simple install

Acrylic adhesive backing: peel the liner and press it onto a clean jamb.

CONSTRUCTION & SPECIFICATIONS

Material	SBR (styrene butadiene rubber), industrial grade, black, smooth texture
Reinforcement	Polyester fabric, one layer for every 1/16" of thickness
Size	36" L x 1" W x 1/4" thick (914 x 25 x 6.4 mm), per strip
Tolerances	Thickness ±0.031"; width ±0.250"; length ±0.250"
Hardness	Durometer 75A ±5 (hard)
Tensile strength	700 psi
Rating	ASTM D2000 AA 707 Z1 (Type A, Class A)
Performance	Highly shape retaining, highly tear resistant, ultra abrasion resistant, ultra water resistant
Backing	Acrylic adhesive, rated -40°F to 300°F
Max. temperature	170°F (rubber)
Compliance	RoHS 3; REACH. Made in the USA
Quantity	4 strips per Portland Loo front door

ORDERING OPTIONS

OPTION	STANDARD	NOTE
Front door kit	4 x 36" SBR strips STD	Ask for SBR rubber, not the chase door foam

VIEWS

INSTALL TIP Clean the jamb with isopropyl alcohol and let it dry. Peel the liner, press each strip firmly along its full length, and adjust the door closer so the door seats against the rubber without slamming.