

HINGE-SIDE ID DECAL

ALL-USER RESTROOM STICKER

A UV-printed, matte-laminated vinyl decal that identifies the Portland Loo as an all-user, accessible restroom from the hinge side of the door.

**9" x 8"**

WITH 1/2" RADIUS CORNERS

UV print

FLAT PRINT ON ORACAL 3165GRA VINYL

Matte laminate

ORAGUARD 210 CUTS GLARE

Kiss-cut

PEEL AND STICK ON THE PANEL

OVERVIEW

The All-User Restroom sticker carries the same artwork as the Portland Loo's tactile placard: a toilet symbol, the International Symbol of Accessibility and the words "ALL-USER RESTROOM", in white on blue. It is a flat, kiss-cut decal, so it peels off its liner and applies directly to the Loo's wall panel.

It mounts on the hinge side of the Loo, opposite the ADA tactile placard on the strike (handle) side, so the restroom is clearly identified from either approach. The matte laminate protects the UV print and keeps the sign readable in direct sun.

KEY FEATURES

01 Matches the tactile placard

Same symbols, wording and blue as the ADA placard, for a consistent look on both sides of the door.

03 Low-glare matte finish

Oraguard 210 matte laminate over a UV flat print keeps the graphics crisp and easy to read.

02 Hinge-side identification

Labels the restroom from the hinge side, where the strike-side placard can't be seen.

04 Simple to apply

Kiss-cut to shape with 1/2" radius corners. Peel the liner and press it onto a clean panel.

CONSTRUCTION & SPECIFICATIONS

Size	9" W x 8" H (229 x 203 mm), 1/2" (13 mm) radius corners
Type	Kiss-cut vinyl decal on a release liner
Film	Oracal 3165GRA
Print	UV flat print
Laminate	Oraguard 210, matte
Graphics	Toilet symbol and International Symbol of Accessibility, with "ALL-USER RESTROOM"
Colors	White graphics on blue
Placement	Hinge side of the Loo, opposite the ADA tactile placard on the strike (handle) side
Note	A flat decal, not a tactile sign. It supplements, and does not replace, the tactile placard with braille

ORDERING OPTIONS

OPTION	STANDARD	AVAILABLE ON REQUEST
Sticker	9" x 8" all-user decal STD	—
Companion signs	—	All-User Restroom Tactile Placard; Title 24 Restroom Door Sign

VIEWS



LAYOUT & DIMENSIONS



HINGE SIDE OF THE LOO



INSTALLED CLOSE-UP

INSTALL TIP

Clean the panel with isopropyl alcohol and let it dry. Position the sticker on the hinge side of the Loo, level and at about the same height as the tactile placard on the strike side, then peel the liner and squeegee from the center out to remove air.